


**KitchenAid**

Dishwasher

**MODELS:**

KDFM704KPS3 (Stainless)


# DOOR AND PANEL PARTS



# DOOR AND PANEL PARTS

<u>Bill No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Bill No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Bill No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts:	5		Access Panel	10	W10915583	Insulation, Front Panel
	W11323304	Owners Manual		W11120573	Black	11	W10682757	Band Nut, Front Panel
	W11350912	Energy Guide	6		Panel, Front (includes Item 11)	12	W11438578	Screw, Black
	W11366140	Tech Sheet		W11233313	Stainless	13		Top Panel
2		Arm, Hinge	7	W13688703	Cover, Handle Pocket		W11467732	Black
	W11352330	Left Hand	8	W10513880	Insulation, Multi-Layer	14	W11354553	Screw
	W11352370	Right Hand	9	W11033694	Insulation, Single Layer	15	3450000	Screw
3	W11377160	Cross Brace, Door						
4	W10273571	Screw						

# CONTROL PANEL AND INNER DOOR PARTS




# CONTROL PANEL AND INNER DOOR PARTS

Item No.	Part No.	Description
1		Console Assembly (Includes Insert)
	W11496910	Block
2	W11336543	Juniper Door
3	W13889348	Juniper, Lt.
4	W10711284	Screw (Lump)
5	W11091934	Latch Assembly (Includes Switch)
6	W11534457	Control, Electronic
7	W11025934	Seals, Vent (Also Order Gasket)

Item No.	Part No.	Description
8	3430071	Screw
9	W13349403	Screw
10	W11099822	Inner Door Assembly
11	W11583237	Seal, Door Bottom
12	W11543440	Wiring Harness, Main (Includes Thermostat & Fuse)
13	W11084667	Wiring Harness, inner Door
14	W11090543	Dispenser Assembly
15	W11090927	Seal, Console/Door

Item No.	Part No.	Description
16	W11033555	Hanger, Control
17	W11039720	Vent Assembly (Includes Fan)  (Also Order Gasket)
18	W11039734	Duct, Vent
19	W11033413	Screw
20	W11331505	Fuse, In-line
21	W13349403	Screw


# TUB AND FRAME PARTS



# TUB AND FRAME PARTS

<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W1122459	Tub Assembly (Includes gasket)	12	W11336176	Foot Switch	24	W11362501	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, 2 2 Brackets)
2	W11225744	Base, Terminal Box	14	W11184382	Plug, Tub			
3	W11033385	Gasket, Tub	15	W11429970	Water Inlet Assembly	25	W11522143	Heater Element Assembly
4	W11423374	NUL Water Inlet	16	W11433388	Leg, Leveling	26	3400392	Screw
5	W11030487	Shike, Latch	17	3373126	Wasket, Fringed Cup			
6	W11236374	Screw	18	3400014	Screw, Grounding			
7	W11165391	Seal, Cabinet	19	W11277003	Screw			
8	W11025382	Drip Tray	20	W11226749	Cover, Terminal Box			
9	W11025383	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025388	Funnel Extension		W11520522	Left Hand			
11	3265145	Bracket, Undercounter		W11520523	Right Hand			
12	W11165393	Cover, Tub Corner	22	W11221821	Shield, Top Sound			
			23	W11122441	Terminal Block			


# PUMP, WASHARM AND MOTOR PARTS



# PUMP, WASHARM AND MOTOR PARTS

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
1	W1122133	Pump Assembly	13	W10900337	Hose, Bottom	24	W1122281	Clamp, Hose
2	W11254332	Isolator, Front Motor	14	W11035702	Motor, Drain	25	W11036151	Hose
3	W10351545	Diffuser, Inlet	15	W11121134	Hose, Drain	26	W11035143	Clp, Hose
4	W11254330	Hanger, Front Motor	16	W10303433	Disc, Diverter	27	W13455555	Clamp, Hose
5	5741252	Screw	17	W11025552	Bracket, Rear Motor	28	W11036237	Hose, Inlet
6	W10351547	Check Valve, Drain	18	W11412271	Fastener	29	W11225575	Clamp, Hose
7	W11043455	Wash Arm Assembly	19	W11125174	Indicator, Optical (Fast)	30	W11033554	Gate
8	W11103655	Filter Assembly	20	370445	Clamp, Hose	31	301905	Clamp, Hose
9	W10330335	Ring, Valve	21	W11153415	Bracket, Thermostat	32		Diverter Valve Motor (Not Serviced)
10	W11345228	Motor & Sump Assembly	22	W11153055	Thermostat (Included with Main Wiring Harness)	33	W11034555	Sump (Includes Seal and Diverter)
11	W11036553	Isolator, Rear Motor	23	W11025570	Fill Valve Assembly	34	W10753575	Capacitor
12	W11250355	Hose, Pressure				35	W10457002	Screw


# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10872338	Feed Tube Assembly	4	W11174340	Upper Sprayer Assembly	6	W10862638	Retainer, Docking (2nd Level)
2	W11039838	Retainer	5	W10303485	Cover, Diverter	7	W10862639	Retainer, Docking (3rd Level)
3	W11039852	Sprayer, Third Level						


# UPPER RACK AND TRACK PARTS



# UPPER RACK AND TRACK PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W112847819	Distrack, Upper	7		Track, Assembly	13	W11179788	Roller
2	W11312237	Clp, Straws		W11212732	Left Hand	14	W11172270	Roller
3	W11100179	Leveler, Adjuster Arm		W11212734	Right Hand			
4	W11180609	Clp, Adjuster Arm	8	W11289882	Handle, Distrack Front			
5	W11357699	Buttop, Adjuster Arm	9	W11289881	Handle, Distrack Rear			
6		Adjustment Assembly	10	3741232	Roller			
	W11289882	Left Hand	11	W11189538	Time Row, Fold Down			
	W11289879	Right Hand	12	W11179783	Clp, Pilot			


# LOWER RACK PARTS



# LOWER RACK PARTS

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
1	WH1234524	Drawer, Lower	5	WH1235272	Tire Row, Fox Down	9	WH1235222	Handle, Drawer Front
2	WH1123748	Wheel & Transport Assembly	6	WH1235658	Retainer, Fox Row	10	WH1235658	Handle, Drawer Rear
3	WH1251759	Staircase Saddle Assembly	7	WH1235883	Tire Row, Stair	11	ST41232	Screw
4	WH1257118	Lid, Silverline Saddle	8	WH1409278	Retainer, Siding Tire Row	12	WH125773	Universal Saddle

# THIRD LEVEL RACK AND TRACK PARTS



# THIRD LEVEL RACK AND TRACK PARTS

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
1	W1173727	Rack, Third Level	5	W1285620	Handle, Dishrack Front	11	W16830823	Drive Box Assembly, Mainline
2		LED Lt. Track Assembly	5	W1285661	Handle, Dishrack Rear	12	W1101880	Cover, Wash Tube
	W11047613	Left Hand	7	3741232	Screw	12	W16821824	Tube, Mesh
	W11047615	Right Hand	8	W11200101	Cup Guard	14	W16800244	Nut, Top
3	W11154071	Hanger, Tube	5	W11057523	Silverware Tray			
4	W11130703	Mount, Dishrack	15	W12856577	Bracket, Front Hanger			

# OPTIONAL PARTS (NOT INCLUDED)

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
	4288277	Sealer Kit
	W11381854	External Drain Hose, 12 FT.
	W11385011	Power Cord Kit (Straight)
	W11385014	Power Cord Kit (Right Angle)
	4288073	Steam Relief, Power Cord (Metallic)
	W11385158	Compression Hose Fitting, Water Line
	W10278838RE	Fill Hose Kit